

調布市せんがわ劇場 照明負荷番号一覧表

負荷名称	DMX番号		負荷名称	DMX番号	
LED BOR 中	191/192		DL ①	26	舞台
LED BOR 外	193/194		DL ②	27	
BOR W	1		DL ③	28	客席・前
BOR 78	2		DL ④	29	
BOR 72	3		DL ⑤	30	客席・中
UH ①	4	#72	DL ⑥	31	
UH ②	5	#78	DL ⑦	32	客席・後
UH ③	6	#71	DL ⑧	33	
LH ①	15	#72	予備ボタン ①	34	PAブース
LH ②	16	#59	予備ボタン ②	35	客席階段当て
LH ③	17	#22	予備ボタン ③	36	
1SUS ①	7		PS ①	107	
1SUS ②	8		PS ②	108	
1SUS ③	9		PS ③	109	
1SUS ④	10		PS ④	110	
1SUS ⑤(PD)	91		PS ⑤	111	
1SUS ⑥(PD)	92		PS ⑥	112	
1SUS ⑦(PD)	93		1CL ①	101	
2SUS ①	11		1CL ②	102	
2SUS ②	12		1CL ③	103	
2SUS ③	13		1CL ④	104	
2SUS ④	14		1CL ⑤	105	
2SUS ⑤(PD)	94		1CL ⑥	106	
2SUS ⑥(PD)	95		1FRO下 ①	113	
2SUS ⑦(PD)	96		1FRO下 ②	114	
FC ①	18		1FRO下 ③	115	
FC ②	19		1FRO上 ①	116	
FC ③	20		1FRO上 ②	117	
FC ④	21		1FRO上 ③	118	
FC ⑤	22		2FRO下 ①	119	
FC ⑥	23		2FRO下 ②	120	
FC ⑦	24		2FRO下 ③	121	
FC ⑧	25		2FRO上 ①	122	
			2FRO上 ②	123	
			2FRO上 ③	124	
予備1 ①	140		1.5CL ①	128	
予備1 ②	141		1.5CL ②	129	
予備1 ③	142		1.5CL ③	130	
予備2 ①	143		2CL ①	131	
予備2 ②	144		2CL ②	132	
予備2 ③	145		2CL ③	133	